



MAINTENANCE SCHEDULE

2006 -2008 LR3

Owner's Name: _____

Date: _____ Mileage _____ RO#: _____

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	6	12	18	24	30	36	42	48
	⊖ MILES (Thousands)	7.5	15	22.5	30	37.5	45	52.5	60
	⊙ KM (Thousands)	12	24	36	48	60	72	84	96
⊙ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks, Lube door checks, hood latch & fuel flap.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Inspect serpentine drive belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace serpentine drive belts (V6 at 105k miles)									
Replace serpentine drive belt (at 150k miles)									
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)							<input type="checkbox"/>		
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years)									
Replace spark plugs (V6 at 90k miles)									
Replace spark plugs (V8 at 105k miles)									
Replace air-cleaner element									<input type="checkbox"/>
4. UNDER VEHICLE									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures are set to recommended levels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tires for damage and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric parking brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.					<input type="checkbox"/>				<input type="checkbox"/>
Check torque of tie rod ends. Tighten to 76 Nm (56 lbf.ft)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions					<input type="checkbox"/>				<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
Replace flexible brake hoses (6 years)*									
Change automatic transmission fluid and filter (10 years)									
Change transfer gearbox oil (at 75k and 150k miles)									
Change front and rear axle oil (10 years or 150k miles)									
Change locking differential oil (at 75k and 150k miles)									
5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED									
If fault lamps are illuminated use T4 to find the faults and report	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No	<input type="checkbox"/>	Yes/No
6. ROAD TEST									
Select LOW range, move vehicle 60 ft and select HIGH			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time.

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



MAINTENANCE SCHEDULE

2006 -2008 LR3

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	A	O&F	B	O&F	A	O&F	B
	TIME (Months)	54	60	66	72	78	84	90	96
	⊙ MILES (Thousands)	67.5	75	82.5	90	97.5	105	112.5	120
	⊙ KM (Thousands)	108	120	132	144	156	168	180	192
⊙ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check door locks, Lube door checks, hood latch & fuel flap.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Inspect serpentine drive belts			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace serpentine drive belts (V6 at 105k miles)							<input type="checkbox"/>		
Replace serpentine drive belts (V8 at 150k miles)									
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)					<input type="checkbox"/>				
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years)									
Replace spark plugs (at 90k miles)					<input type="checkbox"/>				
Replace spark plugs (V8 at 105k miles)							<input type="checkbox"/>		
Replace air-cleaner element									<input type="checkbox"/>
4. UNDER VEHICLE									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures are set to recommended levels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tires for damage and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric parking brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check exhaust system for leaks and damage			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect steering ball joints for wear, damaged dust covers					<input type="checkbox"/>				<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots, ball joints and drive shafts.					<input type="checkbox"/>				<input type="checkbox"/>
Check torque of tie rod ends. Tighten to 76 Nm (56 lbf.ft)			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions					<input type="checkbox"/>				<input type="checkbox"/>
Inspect electrical harnesses for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
Replace flexible brake hoses (6 years)*					<input type="checkbox"/>				
Change automatic transmission fluid and filter (10 years)									
Change transfer gearbox oil (at 75k and 150k miles)			<input type="checkbox"/>						
Change front and rear axle oil (10 years)									
Change locking differential oil (at 75k and 150k miles)			<input type="checkbox"/>						
5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED									
If fault lamps are illuminated use T4 to find the faults and report	Yes/No	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. ROAD TEST									
Select LOW range, move vehicle 60 ft and select HIGH			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time.

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.

