



MAINTENANCE SCHEDULE

2006 - 2008 Range Rover

Owner's Name: _____

Date: _____ Mileage _____ RO#: _____

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	OIL	O&F	#1	O&F	OIL	O&F	#2
	TIME (Months)	6	12	18	24	30	36	42	48
	⊕ MILES (Thousands)	7.5	15	22.5	30	37.5	45	52.5	60
	⊕ KM (Thousands)	12	24	36	48	60	72	84	96
⊕ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation of front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate top edge door seals			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Check battery condition, fill electrolyte, clean terminals			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect serpentine drive belts and if equipped Supercharger belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace drive belts (at 150k mi)*									
Replace Supercharger drive belt (if equipped) (at 105k mi)*									
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)							<input type="checkbox"/>		
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years) *									
Replace spark plugs (at 105k miles) *									
Replace air-cleaner element*									<input type="checkbox"/>
Replace fuel filter (at 150k mi) *									
4. UNDER VEHICLE									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric park brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures condition and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition/operation of suspension and steering components, boots and drive axles					<input type="checkbox"/>				<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
Change automatic transmission fluid and filter (10 years or 150k miles) *									
Change transfer gearbox oil (75k and 150k miles) *									
Change electronic rear differential oil (75k and 150k miles) *									
Change front and rear axle oil (10 years) *									
5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED									
If fault lamps illuminated use T4 to find the faults and report		Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No	Yes/No
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. ROAD TEST									
Select LOW range, move vehicle 60 ft and select HIGH			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



MAINTENANCE SCHEDULE

2006 - 2008 Range Rover

Owner's Name: _____

Date: _____ Mileage _____ RO#: _____

MAINTENANCE INTERVAL AND TYPE	TYPE	O&F	OIL	O&F	#1	O&F	OIL	O&F	#2
	TIME (Months)	54	60	66	72	78	84	90	96
	☉ MILES (Thousands)	67.5	75	82.5	90	97.5	105	112.5	120
	☉ KM (Thousands)	108	120	132	144	156	168	180	192
☉ "Nominal" distance values for normal driving. See Passport to Service for additional information.									
1. VEHICLE INTERIOR									
Reset the Service Interval Indicator		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check operation of all lights, warning indicators and horn			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check operation of front/rear wiper washer systems. Check blades			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace pollen filter			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check condition and security of seats and seat belts					<input type="checkbox"/>				<input type="checkbox"/>
2. VEHICLE EXTERIOR									
Anti-corrosion check. Use Corrosion Perforation Form			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate top edge door seals			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
3. ENGINE COMPARTMENT									
Check battery condition, fill electrolyte, clean terminals			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect serpentine drive belts and if equipped Supercharger belt			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Replace drive belts (at 150k mi)*									
Replace Supercharger drive belt (if equipped - 105k mi) *							<input type="checkbox"/>		
Check and top-up brake, PAS and windshield washer fluid			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change brake fluid (3 years)					<input type="checkbox"/>				
Check coolant level and freeze protection level			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Change engine coolant (10 years) *									
Replace spark plugs (at 105k miles) *							<input type="checkbox"/>		
Replace air-cleaner element*									<input type="checkbox"/>
Replace fuel filter (at 150k mi) *									
4. UNDER VEHICLE									
Change engine oil and replace filter		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Remove road wheels			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for brake pad wear, caliper leaks and disc condition			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check adjustment of electric park brake			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Check tire pressures condition and tread depth			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Lubricate wheel centers.			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Install road wheels to opposite side of the vehicle – except uni-directional tires which install on same side			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect for under vehicle fluid leaks			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Inspect condition and operation of suspension and steering components, boots and driveshafts					<input type="checkbox"/>				<input type="checkbox"/>
Inspect brake, fuel lines, PAS hoses and unions for correct routing and damage					<input type="checkbox"/>				<input type="checkbox"/>
Change automatic transmission fluid and filter (10 years or 150k miles) *									
Change transfer gearbox oil (75k and 150k miles) *			<input type="checkbox"/>						
Change electronic rear differential oil (75k and 150k miles) *			<input type="checkbox"/>						
Change front and rear axle oil (10 years) *									
5. REMEDIAL WORK/SERVICE CAMPAIGN NEEDED									
If fault lamps are illuminated use T4 to find the faults and report	Yes/No	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6. ROAD TEST									
Select LOW range, move vehicle 60 ft and select HIGH			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Road test vehicle			<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
Record performance of Service in Passport to Service		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

* Labor cost not included in scheduled time

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.



MAINTENANCE SCHEDULE

2006 - 2008 Range Rover



CAUTION: Do not perform two wheel roller tests.

Loaded I/M testing of permanent four wheel drive or traction control equipped vehicles must be conducted on a four wheel drive synchronized dynamometer. Otherwise a non-loaded test procedure must be followed.



NOTE: Some items do not need to be carried out at every service. All required steps in a specific service are identified in the column headed by the mileage/month by a check box -

IMPORTANT



CAUTION: Should a Range Rover vehicle have a high proportion of short journeys or operate in severe conditions, Land Rover North America, recommends that the maintenance intervals be cut in half for "Arduous Use" – Oil Changes at 3,750 miles (6,000 km) and Service Intervals of 7,500 miles (12,000 km).

For Arduous Use at the least the following precautions must be observed:

- After 50 miles (80 km) of continuous use in severe off road conditions – wading, deep mud, and abrasive grit/slurry – the electric park brake should be inspected, cleaned and adjusted. The serpentine engine drive belts should also be inspected and cleaned.
- If a vehicle is used extensively in arduous/ off road conditions, the road wheel speed sensors, brake pads and calipers should be checked for abrasive wear every 1000 miles (1500 kilometers).
- When the vehicle is used in dusty or off road conditions, or is subjected to deep wading, frequent replacement of the air cleaner may be required.

For full details regarding the operations contained in this maintenance check sheet, please refer to the Workshop Manual.

Comments/Remedial Action Required

NOTIFICATION OF SERVICE REQUIREMENTS:

- ◆ Your next service is due in six (6) months or 7,500 miles (12,000 km), whichever is sooner.
- ◆ Please refer to your owner's manual for **Service Recommendations** if your vehicle is used extensively off-road, or under severe conditions.
- ◆ The owner or operator is responsible for **Owner Checks** listed in the Owner's Manual. These are *not* included in the Service Schedule.